

CARE INSTRUCTIONS

Wash well before first use. Avoid cooking at excessive temperature as overheating can damage the stainless steel.

Use only with wooden or plastic cooking utensils. Never cut food inside the cookware. Use caution when handling cookware as handles and knobs can become hot with use. Always use pot-holders to prevent burning.

Wash the cookware after first use with warm, soapy water and soft sponge. Never use steel wool and other abrasives.

Dishwasher safe.