

Fibre Optic Tree

Indoor Use Only

Catalogue No. 1.8m FT183050

Thank you for purchasing this product. Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

INSTRUCTIONS FOR USE

- Remove the product from the packaging taking care not to damage or twist the wires.
- Unfold the metal base and install the screws as shown in fig 1. then tighten the screws to hold the tree in place.

fig.1



fig 2



fig.3



- Connect the cable from the tree to the transformer as shown in fig2.
- Insert the upper tree section into the middle hole of the lower tree section then connect the cable/s from upper and lower sections. See fig 3
- Shape the tree by spreading the branches to create a full and natural look.
- Make sure that the power cable is completely unravelled and there are no snags in the cable.
- To operate, plug the transformer into mains supply, indoors.

LEDs

- Non-Replaceable Light Emitting Diode (LEDs): 3V 0.025W

TRANSFORMER

- This product is supplied with a DC 12V 9VA transformer and should only be used with this transformer.

FOR SAFETY

- It is very important that the product is NEVER DIRECTLY connected to the mains supply without using the transformer.
- FOR INDOOR USE ONLY.
- Do not damage the insulation of cable or bulb holder.
- Do not secure the wiring of the product with staples or nails
- Do not close doors or windows on the product as this may damage the wiring insulation.
- Do not lay the cable under carpets or where it can be damaged.
- Ensure that cables are fully unwound and sited where they will not become damaged or present a tripping hazard.
- Do not connect this product electrically to any other product.
- Do not connect the product to the mains supply while it is in the packaging.
- Do not allow any plastic part to come into contact with heat or flame.
- Do not unscrew or twist the LED.
- Ensure table top transformers are positioned on flat, stable, heat resistant surfaces.
- Unplug the product when leaving the house, when retiring for the night or if left unattended
- Do not overload wall sockets. Use different sockets around the house to plug in multiple lights to balance the load.
- For decorative purposes only. Not suitable for use in play by children
- Please retain this information for future reference.



Complies with safety requirements of BS EN 60598

For replacement parts email: accessories@premierdec.com



Manufactured and Imported by:
PREMIER DECORATIONS LTD
United Kingdom: HA4 0EJ
EU: Inniscarra, Co Dublin, D24 E029
consumer@premierdec.com