





1M PRE LIT CHRISTMAS TREE WARM WHITE


PLU 158989
Assembly and Care Instructions



1. Slide the feet into the groove of knob at the bottom of the tree stem one by one until the feet fixed in all three directions.



2. Shape the branches and tips working from the bottom to the top. Start with tips farthest from the pole and fan out one to the right, one to the left and one at the center of the main stem. After shaping the entire tree arch following the previous step, slightly sweep up all branch tips for a uniform look. Shift branches to fill any gaps. Your Jolly Sleigh Christmas Tree is now completed and ready to be decorated and lighted up.



STORAGE INSTRUCTIONS

1. Remove all ornament decorations and batteries.
2. Dismantle the stand - but remember to keep all the components.
3. We recommend that you tether or cello tape the box to avoid any lost items.
4. Before you place the tree into storage, check that you have not forgotten any components.
5. When not in use, please store your Christmas tree in a cool, dry place away from sunlight. Exposing your tree to excessive heat or humidity may damage your tree.