


















# CRAZY GOLF

## Instructions

3+  
years



 x 1	 x 1	 1	
 x 1	 x 1	 x 1	 x 2
 x 2	 x 2	 x 2	 x 2
 x 1	 x 4	 x 1	



**Warning.** Not suitable for children under 3 years. Small parts. Choking Hazard. Warning. Do not aim at eyes or face. Packaging is not a toy. Remove tags, ties and packaging and any accessories before giving to a child. Examine the toy regularly for wear before giving to a child. Adult supervision is required at all times whilst children play with this toy. Adult assembly is required. The assembly should be checked by an adult before each use. Do not use if damaged. Images are for illustrations only. Colours and contents may vary from that shown. Please retain this information for future reference.

**PRODUCT MAY VARY SLIGHTLY FROM IMAGE SHOWN.  
PLEASE KEEP PACKAGING AND INSTRUCTION MANUAL  
FOR FUTURE REFERENCE.**

**WARNING: DO NOT AIM AT EYES OR FACE.**

**WARNING: FOR SAFETY REASONS,  
REMOVE ALL TAGS, LABELS, AND PLASTIC  
FASTENERS BEFORE GIVING THIS TOY TO  
YOUR CHILD.**

PLU-155903  
OGALAS ULC  
UNIT 4 PARKWAY HOUSE  
BALLYMOUNT DRIVE  
DUBLIN, D12 ECR9  
MADE IN CHINA

