

## **Instructions**

For temporary use only, do not leave on window when not in use. Do not leave the blind on windows in direct sunlight for prolonged periods of time.

### **Attaching the blind**

1. Gently press a corner suction cup onto the window and work across the window attaching each suction cup to the glass. Press centre of suction cup firmly onto glass for 10 seconds to attach. Moisten the suction cup slightly if required.
2. Adjust blind to desired window size using the velcro patches
3. Continue down both sides of the blind and finally along the bottom

### **Removing the blind**

1. Do not grab blind and pull. This puts pressure on the blind and risks damage to the window glass. Remove each suction cup one at a time. Do not use on windows that have damaged edges, visible chips, cracks or any other glass or frame damage. The blind can be safely applied to normal single or double glazed windows in good condition.

### **Warning**

This product and carrying bag is not a toy and is designed for parental use only. When not in use keep the blind and carrying bag out of reach of children. Keep the blind well out of reach of children when in use. Do not use directly over child's bed. Pull cots and beds away from windows. Check frequently that the blind is properly fastened in its position and that cots and beds have not moved into touching distance of blind. Suction cups may pose a choking hazard so keep away from small children. This blackout blind is for its intended use only.