size: 21 X 29.7 cm size: 21 X 29.7 cm



CHARCOAL RATTAN RELAXING SWING CHAIR **Model Number: 145988 Assembly Instructions**

IMPORTANT: PLEASE RETAIN THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE. PLEASE READ CAREFULLY.

WARNING:

This item is for domestic use only.

Two people are required to assemble this item.

Assemble this item on a flat, solid and even surface.

Make sure that all the necessary pieces are in the carton before starting the assembly. Maximum Loading Capacity is 100kg totally.

Keep away from fire and inflammable objects.

Before using this item ensure it is firmly fixed in place and on a flat solid even surface. Before each use, check that all screws, legs and materials are secure, and the seat is in good condition, if in doubt, do not use.

Never lean forwards/backwards on the seat.

Excessive movement of the swing could result in risk of tipping over and causing injury.

Ensure that the safety strap provided is in place before use as per the instruction

This is not a climbing frame or toy.

CLEAN AND CARE

Do not use, or leave out, in adverse weather conditions (including wind and rain), or during the winter months.

Damp wipe only and dry naturally.

Please ensure furniture is dry before storing.

Periodically ensure all the screws and fixings are secure and the item is stable.

We strongly advise covering up or storing away your furniture when not in use to protect it from the elements.

Care must be taken when operating the movable mechanism of this item. Keep your fingers away. Children should be supervised.

Please store all cushions indoors when not in use.

Your product is guaranteed against manufacturing defects for 12 months from date of purchase. Please retain your receipt as proof of purchase.





OGALAS ULC D12 ECR9 **MADE IN CHINA**

