






































# Assembly Instructions for 145975

															
				A	1	B	1	C	4						
															
				D	1	E	2	F	2						
															
				G	1	H	1	N	1						
															
				O	1	P	1	Q	1						
														 M10*96	
				Z2	1	R	1	M	1	S	1	T	1	I	1
 M8*20		 M8*75		 M8*68		 M8*20									
K	8	U	4	V	2	Z1	2	W1	1	X1	1	Y1	2		
															
															
								AA		1		BB		2	







1 2  
3 4





5 6  
7 8





9 10  
11

