














Kids Gazebo Assembly Instruction PLU-052316

A: Contents list

	Tube 1#: 4 pcs
	Tube 2#: 4 pcs
	Tube 3#: 4 pcs
	Tube 4#: 4 pcs
	Tube 5#: 4 pcs
	Tube 6#: 4 pcs

	A-1 pc
	B-4 pcs
	C-4 pcs
	8 pcs
	4 pcs

B: Structure



1. Fix the tubes together and connect the ends of the tubes by the plastic parts supplied according to the above image.
2. Pull the cover over the tube structure and fix it to tube 6# then to the base.

SAFETY DIRECTIONS

- 1) Assembly by an adult only.
- 2) Not suitable for children below 3 years old because of:
 - (a) Choking hazard - small parts
 - (b) Strangulation hazard - long cord
- 3) Keep the cover and sidewalls away from fire.
- 4) Not suitable for use in severe or adverse weather conditions.
- 5) For use only as a temporary shelter.
- 6) For outside and occasional use only.
- 7) Keep away from fire.
- 8) Do not use in extreme weather conditions.

WARNING

Do not use in severe or adverse weather conditions (especially high winds).
 Keep away from fire and inflammable objects.
 For use only as a temporary shelter.
 For outside and occasional use only.
 Never place hot/cooking appliances inside or near the product.

