

warmlite
heating the heart of the home

PERSONAL HEATER

YOUR SAFETY &
INSTRUCTION MANUAL
PLEASE READ CAREFULLY

MODEL **WL44014N**



This product is only suitable for well insulated spaces or occasional use.



www.warmlite.co

PRODUCT SAFETY

When using **any** electrical appliance, basic safety precautions should always be followed including the following:

- Check that the voltage of the main circuit corresponds with the rating of the appliance before operating.
- This product is only suitable for well insulated spaces or occasional use
- If the plug or appliance is damaged, stop using the appliance immediately and seek advice from the manufacturer, its service agent or a similarly qualified person.
- The use of accessory attachments is not recommended by the appliance manufacturer apart from those supplied with this product. **DO NOT** use extension cords with the appliance.
- Switch off at the wall socket then remove the plug from the socket when not in use or before cleaning.
- Switch off and unplug before fitting or removing tools/ attachments, after use and before cleaning.
- Close supervision is necessary when any appliance is used by or near children.
- Children should not play with the appliance.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Cleaning and user maintenance should not be undertaken by children without supervision.
- Take care when any appliance is used near pets.
- **DO NOT** use this product for anything other than its intended use.
- This appliance is for household use only.
- **HIGH VOLTAGE & HOT SURFACE DO NOT COVER**
- **DO NOT** immerse cords, plugs or any part of the appliance in water or any other liquid.

- This appliance is for household use only.
- **DO NOT** use the appliance outdoors.
- Ensure that the heater is not positioned close to curtains, furniture or any combustible materials as this could create a fire hazard.
- The heater must not be located immediately below a mains socket outlet.
- This product is only suitable for well-insulated spaces and occasional use.
- **DO NOT** cover the heater as this may lead to a fire risk.
- **DO NOT** obstruct any of the openings of the heater.
- **DO NOT** insert any object through any openings on the heater.
- Check all inlets and outlets from time to time for accumulated dust.
- **DO NOT** use the heater in areas where flammable liquids are stored or where flammable fumes may be present.
- **DO NOT** operate the heater on a remote timer, or leave on overnight.
- When not being used, please unplug the heater from the mains socket.
- **DO NOT** use the heater in the immediate surroundings of a bath, a shower, a swimming pool or similar indoor locations.
- Always unplug the heater and allow it to cool before moving it from one location to another.
- **DO NOT** attempt to dismantle or repair any part of the heater. This should only be done by a qualified service agent.
- In the unlikely event the appliance develops a fault, stop using it immediately and seek advice from the Customer Support Team.



HIGH VOLTAGE



HOT SURFACE



DO NOT COVER

TECHNICAL DATA

Description:	Personal Heater
Model:	WL44014N
Rated Voltage:	220 - 240V
Frequency:	~ 50/60Hz
Power consumption:	500W

DOCUMENTATION

We declare that this product conforms to the following product legislation in accordance with the following directive(s):

2014/30/EU	Electromagnetic Compatibility Directive.
2014/35/EU	Low Voltage Directive.
2011/65/EU	Restriction of Hazardous Substances Directive.
2009/125/EC	Eco-Design of Energy Related Products.

RK Wholesale LTD Quality Assurance, United Kingdom

WARRANTY

This product is guaranteed for 12 months from the date of original purchase. If any defect arises due to faulty materials of workmanship, the faulty products must be returned to the place of purchase. Refund or replacement is at the discretion of the retailer.

The following conditions apply:

- The product must be returned to the retailer with proof of purchase.
- The product must be installed and used in accordance with the instructions contained in this instruction guide.
- It must be used only for domestic purposes.
- It does not cover wear and tear, damage, misuse or consumable parts.
- RK Wholesale LTD has limited liability for incidental or consequential loss or damage.
- This guarantee is only Valid in the UK and Eire Only.

An extended warranty is available for this appliance.

See back page for details.

WHAT'S IN THE BOX

Instruction Manual

Personal Heater

1. Standby Button
2. Temperature / Speed +
3. Temperature / Speed -
4. Power ON/OFF Switch (Side of unit)
5. LED Display
6. Timer Button
7. Vents



BEFORE FIRST USE:

1. Remove your appliance from the packaging.
2. Locate your appliance in accordance with the safety instructions.
3. Plug the appliance into the mains supply.
4. Your appliance is now ready for normal use.

Dispose of the packaging in a responsible manner.

USING YOUR APPLIANCE

1. Plug the appliance to a 220-240V~ 50/60Hz socket in the wall.
2. To start the heater, push the on/off switch located at the side of the appliance.
3. Pressing the button below the plug, at the back of the appliance, allows you to rotate the plug to 90°. Make sure the plug is secure once this is done.
4. Push the Stand-by button  to activate the heater.

Heating:

1. Press the 'Temperature / Speed +' or 'Temperature / Speed -' buttons to set the desired temperature, from 15° to 30°. The thermostat will now regulate the heater to turn on if the temperature is too low, and off once the desired temperature is reached.
2. Press the 'Temperature / Speed +' or 'Temperature / Speed -' buttons at the same time to speed up the fan or slow it down. The display will flash for a moment, showing the selected speed setting, before going back to showing the current temperature.

Turning off the Heater:

To turn your heater off at any time press the Stand-By button. The heating element will stop and the fan will operate for approximately 60 seconds, allowing your heater to cool down before switching off.

Using the Timer:

1. Power-off: If you set the timer while the heater is on, you set the number of hours after which the heater turns itself off.
2. Power-on: If you set the timer while the heater is set to stand-by, you set the number of hours after which the heater turns itself on.
3. For example, if you want to set the countdown timer to 2 hours, press the 'Timer' button 3 times. The LED will display the number of hours.
4. Your heater will turn off automatically in 2 hours.
5. To stop the heater, push the ON/OFF switch again.

UNPLUG THE PRODUCT WHEN IT'S NOT IN USE.

CLEANING AND MAINTENANCE

- Be sure to turn off the appliance, switch off the power supply at the wall socket and disconnect the plug before attempting to clean it.
- Wait for the heater to cool down fully before attempting to clean it.
- ONLY clean the body of the heater with a damp cloth.
- DO NOT ALLOW water into the appliance.
- Never use soap or chemicals which may damage the housing of the heater.
- Allow sufficient drying time before operating again.
- Clean the air inlets and outlets regularly with a vacuum cleaner (at least twice a year).
- When the unit is not in use we recommend that the heater is re-packed in its original packaging and stored in a cool, dry place.

DISPOSAL OF THE UNIT

Appliances bearing the symbol shown here may not be disposed of in domestic rubbish. You are required to dispose of old electrical and electronic appliances like this separately.

Please visit www.recycle-more.co.uk or www.recyclenow.co.uk for access to information about the recycling of electrical items.

Please visit www.weeeireland.ie for access to information about the recycling of electrical items purchased in Ireland.

The WEEE directive, introduced in August 2006, states that all electrical items must be recycled, rather than taken to landfill.

Please arrange to take this appliance to your local Civic Amenity site for recycling, once it has reached the end of its life.



WARNING:

DO NOT IMMERSE ANY ELECTRICAL PART OF THE APPLIANCE IN WATER SUCH AS MOTOR UNITS OR PLUGS.

PLEASE SEE CLEANING SECTION FOR FURTHER INSTRUCTIONS.

Model Identifier(s): WL44014N					
Item	Symbol	Valve	Unit	Item	Unit
Heat Output			Type of heat input for electric storage, local space heaters only (select one)		
Nominal heat output	P _{nom}	0.5	kW	Manual heat charge with integrated thermostat	No
Minimum heat output (indicative)	P _{min}	0	kW	Manual heat charge control with room and/or outdoor temperature feedback	No
Maximum continuous heat output	P _{max, c}	0.5	kW	Electronic heat charge control with room and/or outdoor temperature feedback	No
Auxiliary electricity consumption				Fan assisted heat output	No
At nominal heat output	e _{lmax}	NA	kW	Type of heat output/room temperature control (select one)	
At minimum heat output	e _{lmin}	NA	kW	Single stage heat output and no room temperature control	No
In standby mode	e _{lSB}	0.00038	kW	Two or more manual stages, no room temperature control	No
				With mechanic thermostat room temperature control	No
				With electronic room temperature control	Yes
				Electronic room temperature control plus day timer	No
				Electronic room temperature control plus week timer	No
				Other control options (multiple selections possible)	
				Room temperature control with presence detection	No
				Room temperature control with open window detection	No
				With distance control option	No
				With adaptive start control	No
				With working time limitation	Yes
				With black bulb sensor	No
Contact Details:	Imported by RK Wholesale LTD., Berryhill Road, Stoke-on-Trent ST4 2NL				

We hope you enjoy your appliance for many years.

As a thank you for purchasing one of our fantastic products,
we are offering you an extra 1 year peace of mind.

*To receive your extra guarantee period, register your appliance online
within 28 days of purchase by visiting:

www.warmlite.co

Make sure to retain your original receipt.



**Should you have a problem
with your appliance or need any spare parts please call our
Customer Support Team on:**

+44 (0) 333 220 6056

Distributed throughout the UK by RK Wholesale LTD

warmlite
heating the heart of the home