

# Care and Use Stainless Steel Vacuum Flask

Get the best out of your Stainless Steel Vacuum Flask by following these simple care tips.

## General Care

- Before first use, please ensure that your vacuum flask is cleaned with warm water and washing-up liquid.
- For best results from your vacuum flask, before use, pre-fill for about 3 minutes, using either hot water for hot drinks or cold water for chilled drinks.
- Never use a microwave or conventional oven to pre-heat your vacuum flask.
- If your vacuum flask has not been used for some time, rinse with warm water to remove any residual odours.
- Avoid overfilling the vacuum flask. Leave sufficient space in the neck to fit the stopper.
- After filling, always ensure that both the outside cup and stopper are tightly closed.
- Contents should not be left in the container for longer than 24 hours. As soon as possible after every use, wash all parts with warm, soapy water. Rinse all parts thoroughly with clean water. Allow all pieces to dry completely before next use or storage

## Cleaning

- Use warm water and washing-up liquid to clean your vacuum flask after use. Rinse thoroughly with hot water. **DO NOT** immerse in water. Dry thoroughly after leaving it to drain. Store with the stopper off.
- **DO NOT** put your vacuum flask in a dishwasher, unless different information is provided on the product.
- **DO NOT** use abrasive cleaners or scrubbers since they may dull the finish.
- **DO NOT** use bleach or cleaners containing chlorine on any parts of the product.
- To remove difficult stains, fill your vacuum flask with hot water, add one teaspoon of bicarbonate of soda. **DO NOT** put the stopper on the product while using this cleaning method. Soaking overnight produce best results. Always rinse before re-use.

## Caution

- **DO NOT** store dry ice or any carbonated drink as they may cause the stopper to eject forcefully.
- This product must **NOT** be used for keeping milk products or baby food warm or cold, to avoid the possibility of bacterial growth.
- To prevent scalding, always pour contents into a cup. **DO NOT drink directly from the vacuum flask.**
- Keep out of reach of children when the product contains hot liquids.
- **NOT RECOMMENDED FOR USE BY CHILDREN, UNDER 8 YEARS OF AGE:** Keep out of the reach of children, especially when the product contains hot contents, which may burn or scald.
- Always test the temperature of contents before consuming.
- In general, contents should not be left in the container for longer than 24 hours. If contents are left in container longer than 24 hours, or you suspect spoilage, use caution when opening container. Contents spoilage can cause pressure inside the container to build, possibly leading to forceful ejection of the stopper or contents. In such circumstances, before attempting to open container, **ENSURE THE OPENING IS POINTED AWAY FROM THE USER OR OTHER PERSONS TO AVOID INJURY.**
- **DO NOT** use tools or devices to force the container to open.
- If you are unable to open container by hand, do not open it and dispose of it at your local waste facility.