

Care and Use: Vacuum Travel Mug

Get the best out of your Vacuum Travel Mug by following these simple care tips.

General Care

- Before first use, please ensure that your vacuum travel mug is cleaned with warm water and washing-up liquid.
- For best results from your vacuum travel mug, after filling, please leave sitting for 3 minutes before closing the lid and/or hold the button to maintain an open lid position to release excess steam.
- Never use a microwave or conventional oven to pre-heat your vacuum travel mug.
- If your vacuum travel mug has not been used for some time, rinse with warm water to remove any remaining odours.
- Your vacuum travel mug should not be overfilled. Remember to leave sufficient space in the neck to fit the lid.
- After filling, ensure the lid is tightly closed.

Cleaning

- Using warm water and washing-up liquid, clean your vacuum travel mug after each use. Rinse thoroughly with hot water. **DO NOT** immerse in water. Dry thoroughly after leaving it to drain. Store with the lid off.
- **DO NOT** put your vacuum travel mug in a dishwasher, unless different information is provided on the product.
- **DO NOT** use abrasive cleaners or scrubbers since they may dull the finish.
- **DO NOT** use bleach or cleaners containing chlorine on any parts of the product.
- To remove difficult stains, fill your vacuum travel mug with hot water, add one teaspoon of bicarbonate of soda. **DO NOT** put the lid on the product while using this cleaning method. Soaking overnight produce best results. Always rinse before re-use.

Caution

- Keep your travel mug away from direct heat to protect any plastic material from damage.
- **DO NOT** store dry ice or any carbonated drink as they may cause the lid to eject forcefully.
- This product must NOT be used for keeping milk products or baby food warm or cold, to avoid the possibility of bacterial growth.
- The lid may not be leakproof. Always keep upright when full.
- **NOT RECOMMENDED FOR USE BY CHILDREN, UNDER 8 YEARS OF AGE:** Keep out of the reach of children, especially when the product contains hot contents, which may burn or scald.
- In general, contents should not be left in the container for longer than 24 hours. If contents are left in container longer than 24 hours, or you suspect spoilage, use caution when opening container. Contents spoilage can cause pressure inside the container to build, possibly leading to forceful ejection of stopper or contents. In such circumstances, before attempting to open container, **ENSURE THE OPENING IS POINTED AWAY FROM THE USER OR OTHER PERSONS TO AVOID INJURY.**
- If you are unable to open container by hand, do not open it and dispose of it at your local waste facility.