

## Care and Use: Soup / Food Flask

Get the best out of your Soup Flask by following these simple care tips.

### General Care

- Before first use, please ensure that your soup flask is cleaned with warm water and washing-up liquid before first use.
- For best results from your soup flask, after filling, please leave sitting for 3 minutes before closing the lid and/or hold the button to maintain an open lid position to release excess steam.
- Never use a microwave or conventional oven to pre-heat your soup flask.
- If your soup flask has not been used for some time, rinse with warm water to remove any remaining odours.
- Your soup flask should not be overfilled. Remember to leave sufficient space in the neck to fit the lid.
- After filling, ensure the lid is tightly closed.

### Cleaning

- Using warm water and washing-up liquid, clean your soup flask after each use. Rinse thoroughly with hot water. **DO NOT** immerse in water. Store with the lid off.
- **DO NOT** put your soup flask in a dishwasher, unless different information is provided on the product.
- **DO NOT** use abrasive cleaners or scrubbers since they may dull the finish.
- **DO NOT** use bleach or cleaners containing chlorine on any parts of the product.
- To remove difficult stains, fill your travel mug with hot water, add one teaspoon of bicarbonate of soda. **DO NOT** put the lid on the product while using this cleaning method. Soaking overnight produce best results. Always rinse before re-use.

## Caution

- Keep your soup flask away from direct heat to protect any plastic material from damage.
- **DO NOT** store dry ice or any carbonated drink as they may cause the lid to eject forcefully.
- The lid may not be leakproof. Always keep upright when full.
- **NOT RECOMMENDED FOR USE BY CHILDREN, UNDER 8 YEARS OF AGE.**
- Keep out of the reach of children, especially when the product contains hot contents, which may burn or scald.