



Xiongli Decoration Co., Ltd		
Size:	148 (W) x 210 (H)mm	
Color:	■ 100K	Die-cut
Material:	Paper	Front & Back
Coating:	Matt	
Item:	123517	
Date:	03-09-2021	
Designer:	Tom	











## 01 Paddle Height

First of all, paddles must have the right length - about 12"-18" above the head height, approximate hand width.

#### 02 Standstill

Place your feet about one shoulder width away from each other on the board. One hand grabs the T-handle, the other grabs the shaft. Eyes towards the horizon go easy to the knees.


# 03 Always with Leash

Don't forget your Leash stay on the safe



## 04 Forward

Dive the paddle into the water for an arm length and pull it back along the board, where both the upper hand and the leaf should face each other vertically.




## 05 Surfer-Pose

Once the wave takes you, take the typical surfer posture and set a foot further to front. The gives you a better balance and agility.


## SUP Paddle:

Your 3-Piece paddle easily connects together and is fully height adjustable.





fin box. Make sure fin and card slot of fin box in the same position.



# Valves

In order to inflate easily, Remove the valve cover(b)clockwise whirl it(b), Put it(a)in "Output" position. After inflating, screw in valve cover(b) and anticlockwise whirl it(b).





WARNING: Please only use the pump provided or other recommended pumps. DO NOT use an air compressor as you will risk over-inflating the board and severely damaging your SUP beyond repair. Your warranty will be void in the event of damage via over-inflation.

### INFLATION TIPS AND PRECAUTIONS

- <sup>®</sup> The board can be inflated either with our hand pump or an electric pump. The electric pump can inflate the board to a moderate pressure and save a lot of time with about 90% of the required air volume. You will need to use your hand pump to inflate the chambers to the correct pressure.
- Do not use an air compressor.
- add a few pumps of air.
- © Before undertaking a long paddle, inflate the board for a full 24 hours to be sure the board is airtight. If you are seeing a consistent decrease in air pressure, follow the instructions for leak detection in the board repair section of this manual.
- Do not over-inflate the board. A max pressure of 15 PSI is adequate. The easiest gauge of a good working pressure is to have the chambers inflated to a firm pressure when you press on them.
- Oo not pump to a high pressure and let the board sit out in the sun. If the board is going to be in a warm environment, slightly under-inflate the board and allow the heat from the sun to increase the internal pressure. When paddling, the colder temperature of the water may cause a slight loss in chamber pressure. It is a good idea to carry a pump with you so that you can add some air to the chambers if necessary.

#### BOARD CARE AND STORAGE

To ensure extra years of flexibility and bright colors, avoid storing the board where it will be exposed to weather or in direct sunlight.

Please review the following list for storage and board care tips.

- Before storing, hose off the board and let it dry completely to prevent mildew build up.
- Do not use harsh chemicals for cleaning. Most dirt can be removed with a mild soap and fresh water.
- You may store the board inflated or deflated. If you deflate the board, we recommend that you store it in theprotective bag that came with the board.
- We do not recommend hanging the board.
- Do not store in extreme conditions(i.e. above 150F or below -10F).
- Store in a clean, dry place.